

LA SPAZIALE PROGRAM INSTRUCTIONS

Brain Box:

- 1 Temp Controls
- 2 Electronic Controls Testing
- 3 Dose
- 4 ??

1 TEMP CONTROLS

Turn on Dip #1

P1 = Use +&- to change boiler temp. (Press SET)

P2 = Used to change degree change that element goes on at . (Press SET)

P3 = Use +&- to change 120 display setting (Plus +3 lowers temp**) (Press SET)

** TURN OFF DIP ONLY AT P3**

2 ELECTRONICS TESTING

Turn on Dip #2

Display shows 8888

Use set to toggle through different systems.

** Turn off Dip only at 8888 **

3 DOSAGE

110/135/160/230

Turn on dip #3

Push minus (Display shows 0)

Load single

Start

Display shows numbers for shots

Do same for doubles

Press + & - same time (Lights blink)

Press short use +&- to reset numbers press short again.

Repeat for all doses

Press SET to transfer to all groups

Press + & - same time

(Only for different on two groups) Star button will get you to E 2 which is the second control pad.

Turn off Dip #3